

FORM+



NODE | LEV KITCHEN FAUCET

25-0917-XX

FORM+ Care & Maintenance – Plumbing Hardware (Faucets, Fixtures & Stainless Steel Sinks)

General Cleaning

- Use a soft, damp cloth with mild soap and warm water.
- Dry immediately with a soft towel to prevent water spotting.
- Avoid abrasive sponges, steel wool, or harsh cleaning pads.

Polished Finishes

- Wipe regularly with a microfiber cloth to maintain shine.
- Avoid ammonia, bleach, or acid-based cleaners.
- For stubborn spots, use a 50/50 mix of water and vinegar, rinse thoroughly, and dry.

Matte, Brushed & Specialty Finishes

- Clean with a damp cloth only.
- Do not use wax-based or oil-based cleaners.
- Wipe dry after each use to prevent spotting.

Stainless Steel Sinks

- Rinse thoroughly after each use to prevent water spots.
- Use a mild detergent and non-abrasive sponge.
- Dry with a soft towel to prevent mineral buildup.
- Use sink grids or protectors to avoid scratches.

Maintenance Tips

- Inspect aerators every 6 months; clean with vinegar to remove buildup.
- Replace washers or cartridges as needed.
- Check seals and gaskets annually to prevent leaks.