

FORM+



## STAINLESS STEEL 60/40 DOUBLE BOWL UNDER- MOUNT KITCHEN SINK

FP-DB-6040

## FORM+ Care & Maintenance – Stainless Steel & PVD-Coated Kitchen Sinks

### General Cleaning

- Clean daily with mild soap and warm water, rinse thoroughly, and dry with a soft cloth.
- For mineral deposits: use a 50/50 vinegar and water solution, rinse, and dry.
- Polish periodically with a non-abrasive stainless steel cleaner to maintain shine.

### Do Not

- Do not use steel wool, wire brushes, abrasive powders, or bleach-based cleaners.
- Do not leave sponges, rubber mats, or metal cookware sitting in the sink for extended periods, as they may trap moisture and cause discoloration.
- Do not cut or chop directly on the sink surface.

### PVD-Specific Care

- Use microfiber cloths and mild soap for cleaning.
- Dry after each use to prevent water spotting.
- Avoid acidic or alkaline cleaners that can damage the PVD coating.
- Use a sink grid or protector to minimize scratches.
- Polish only with PVD-safe cleaners as recommended by FORM+.

### Maintenance Tips

- Inspect the sink regularly for buildup, discoloration, or signs of wear.
- Always wipe the sink dry after use to prolong finish life.
- Follow all care guidelines to maintain warranty coverage.