



30" SLIDE-OUT HOOD FAN

35-3024-SL-T-MB

FORM+ Care & Maintenance – Hood Fans & Exhaust Vent Systems

General Cleaning

- Clean aluminum or stainless steel grease filters monthly (dishwasher safe if applicable).
- Wipe down exterior surfaces with a soft cloth and mild detergent.
- Avoid abrasive sponges, solvents, or harsh chemicals.

Ventilation

- Inspect ducting every six (6) months to ensure there are no obstructions.
- Replace charcoal filters (recirculating models) every 3–6 months.
- Ensure airflow is not blocked by grease buildup or foreign objects.

Maintenance Tips

- Check fan operation periodically to ensure proper airflow.
- Tighten mounting hardware if vibration occurs.
- Always turn off power before servicing.